

Ash Service Center

MOTIF II A.N.C.

Access to extra features

เข้าถึงคุณสมบัติพิเศษ

TOUCH INTERFACE



Marshall



MARSHALL BLUETOOTH APP

Marshall Group AB (publ)

Download the Marshall Bluetooth app to get the most out of your speaker and keep it up to date with the latest software.



แนะนำอัปเดตเวอร์ชันล่าสุด
ดาวน์โหลดได้ที่นี้

MOTIF II A.N.C.

NOISE CONTROLS

ANC

ANC LEVEL

LOW

MEDIUM

HIGH

OFF

NOISE CONTROL OFF

TRA

TRANSPARENCY LEVEL

LOW

MEDIUM


HIGH

EQUALISER

M1

The original Marshall sound.

MARSHALL



160 Hz 400 Hz 1 kHz 2.5 kHz 6.25 kHz

M2

Select a preset or create your own

BASS BOOST

MARSHALL


CUSTOM

BASS BOOST

MID BOOST

TREBLE BOOST

MID REDUCTION



160 Hz 400 Hz 1 kHz 2.5 kHz 6.25 kHz

CUSTOM ACTION

Noise control

Equaliser

Voice assistant

Volume

Do nothing

SPOTIFY TAP



BATTERY PRESERVATION



ACTION > Noise control

Noise control



Equaliser



Voice assistant



Volume



Do nothing



NOISE CONTROL

ANC

Block out surroundings



Transparency

Let in surroundings



Off



Long touch the left earbud to cycle through the selected noise control modes.

ACTION > Equaliser

Noise control



Equaliser



Voice assistant



Volume



Do nothing



EQUALISER

Marshall

Setting 1

Mid boost

Setting 2

Long touch the left earbud to cycle between the EQ settings above. You can choose settings in "Equaliser".

ACTION > Voice assistant

Noise control



Equaliser



Voice assistant



Volume



Do nothing



VOICE ASSISTANT

Long touch the left earbud to activate your phone's default voice assistant.

Android



Google Assistant

iOS



Siri

ACTION > Volume

Noise control



Equaliser



Voice assistant



Volume



Do nothing



VOLUME

Volume up



Volume down



Long touch the left earbud to increase the volume.

ACTION > Do nothing

Noise control



Equaliser



Voice assistant



Volume



Do nothing



TOUCH CONTROLS

ระบบควบคุมแบบสัมผัส

แตะที่เอียร์บัดข้างซ้าย หรือข้างขวาเพื่อควบคุมเพลง จัดการการโทร และอื่นๆ สามารถปรับแต่งรูปแบบการควบคุมแบบสัมผัสได้ในแอป Marshall Bluetooth

- เล่นเพลง / หยุดเพลงชั่วคราว
- ข้ามเพลงไปข้างหน้า / รับ – วางสาย
- ย้อนเพลงกลับหลัง



แตะค้างไว้ สลับโหมดตัดเสียงรบกวน (A.N.C.)

สลับโหมดโปร่งใส (Transparency)

ปิด / NOISE CONTROL (Off) / ปฏิเสธสาย

**จำเป็นต้องตั้งค่า CUSTOM ACTION ก่อน (ซ้ายหรือขวา)*



แตะสองครั้งแล้วค้างไว้

เพื่อให้ Spotify Tap เริ่มเล่นเพลงตามความชอบของคุณ

**อัปเดตแอปพลิเคชัน Spotify ให้เป็นเวอร์ชันล่าสุดก่อนเริ่มต้นการใช้งาน*



Spotify Tap™

TOUCH CONTROLS (3 MODE)

Standard

Mini

Off

TOUCH CONTROLS > Standard



TOUCH CONTROLS



Standard

Mini

Off

MEDIA

CALL

Play/Pause



Skip forward



Answer/End call

Skip backward



Spotify Tap



Custom actions



Reject call

CUSTOM ACTIONS

Left earbud

Noise control >

Right earbud

Equaliser >

TOUCH CONTROLS > Mini



TOUCH CONTROLS



Standard

Mini

Off

MEDIA

CALL

-



-

Play/Pause



Answer/End call

-



-

Spotify Tap



-

Custom actions



Reject call

CUSTOM ACTIONS

Left earbud

Noise control >

Right earbud

Equaliser >

TOUCH CONTROLS > Off



TOUCH CONTROLS



Standard

Mini

Off

MEDIA

CALL

-



-

-



-

-



-

-



-

-



-

CUSTOM ACTIONS

Left earbud



Right earbud





TOUCH CONTROLS

Customise your earbud touch controls.



SPOTY TAP

Get to know Spotify Tap.



INTERACTION SOUNDS

Customise the Motif II A.N.C. audio prompts.



AUTO-PLAY/PAUSE

In-ear detection will auto-pause and resume playback.



BATTERY PRESERVATION

Extend the battery life span of your earbuds.



ABOUT

Product identifiers and Firmware status.



FORGET DEVICE

Remove Motif II A.N.C. from this app.



TOUCH CONTROLS

Customise your earbud touch controls.



Standard	MEDIA	CALL
	Play/Pause	-
	Skip forward	Answer/End call
	Skip backward	-
	Spotify Tap	-
	Custom actions	Reject call

Mini	MEDIA	CALL
	-	-
	Play/Pause	Answer/End call
	-	-
	Spotify Tap	-
	Custom actions	Reject call

Off	MEDIA	CALL
	-	-
	-	-
	-	-
	-	-
	-	-



SPOTIFY TAP

Get to know Spotify Tap.



Spotify - Music and Podcasts

Listen to Songs and Playlists

Update

★★★★★ 1.1M

Spotify


No. 1 Music

GET STRAIGHT TO THE MUSIC WITH SPOTIFY TAP

Spotify Tap is music to your ears, quite literally. Get the tunes playing with a simple gesture on either left or right earbud.


START THE MUSIC

Double tap and hold to start playing music based on your listening taste.



CHANGE THE MUSIC



Double tap and hold again to skip the tune and cue up new recommendations just for you.





INTERACTION SOUNDS



Customise the Motif II A.N.C. audio prompts.



AUTO-PLAY/PAUSE



In-ear detection will auto-pause and resume playback.





BATTERY PRESERVATION

Extend the battery life span of your earbuds.



STANDARD

PRESERVATION **STANDARD**

Temperature limit

Only charge in room temperature

Max. charge limit

Restrict battery charge to 90%

Charging speed **Fast**

Earbuds charging speed, fast or default

MEDIUM

PRESERVATION **MEDIUM**

Temperature limit

Only charge in room temperature

Max. charge limit

Restrict battery charge to 90%

Charging speed **Default**

Earbuds charging speed, fast or default

MAX.

PRESERVATION **MAX.**

Temperature limit

Only charge in room temperature

Max. charge limit

Restrict battery charge to 90%

Charging speed **Default**

Earbuds charging speed, fast or default



ABOUT

Product identifiers and Firmware status.



Name MOTIF II A.N.C.

Model MOTIF II A.N.C.

Serial number 73400553E333B5B002734
8

Firmware version 5.8.40

The firmware is up to date.



FORGET DEVICE

Remove Motif II A.N.C. from this app.



ARE YOU SURE?

Your Marshall device will be removed from the app. Just add the device again to bring it back.

FORGET DEVICE

Cancel

ash