

Ash Service Center

# MOTIF II A.N.C.

Access to extra features

TOUCH INTERFACE



*Marshall*



## MARSHALL BLUETOOTH APP

Marshall Group AB (publ)

Download the Marshall Bluetooth app to get the most out of your speaker and keep it up to date with the latest software.



**Make sure your Marshall Bluetooth app is up to date**  
Download here

# MOTIF II A.N.C.

## NOISE CONTROLS

**ANC**

ANC LEVEL

LOW

MEDIUM

HIGH

**OFF**

NOISE CONTROL OFF

**TRA**

TRANSPARENCY LEVEL

LOW

MEDIUM


HIGH

## EQUALISER

**M1**

The original Marshall sound.

MARSHALL



160 Hz 400 Hz 1 kHz 2.5 kHz 6.25 kHz

**M2**

Select a preset or create your own

BASS BOOST

MARSHALL


CUSTOM

BASS BOOST

MID BOOST

TREBLE BOOST

MID REDUCTION



160 Hz 400 Hz 1 kHz 2.5 kHz 6.25 kHz

## CUSTOM ACTION

Noise control

Equaliser

Voice assistant

Volume

Do nothing

## SPOTIFY TAP



## BATTERY PRESERVATION



## CUSTOM ACTION > Noise control

- Noise control
- Equaliser
- Voice assistant
- Volume
- Do nothing

### NOISE CONTROL

- ANC**  
Block out surroundings
- Transparency**  
Let in surroundings
- Off**

Long touch the left earbud to cycle through the selected noise control modes.

## CUSTOM ACTION > Equaliser

Noise control



Equaliser



Voice assistant



Volume



Do nothing



### EQUALISER

#### Marshall

Setting 1

#### Mid boost

Setting 2

Long touch the left earbud to cycle between the EQ settings above. You can choose settings in "Equaliser".

## CUSTOM ACTION > Voice assistant

Noise control



Equaliser



Voice assistant



Volume



Do nothing



### VOICE ASSISTANT

Long touch the left earbud to activate your phone's default voice assistant.

Android



Google Assistant

iOS



Siri

## CUSTOM ACTION > Volume

Noise control



Equaliser



Voice assistant



Volume



Do nothing



### VOLUME

Volume up



Volume down



Long touch the left earbud to increase the volume.

CUSTOM ACTION > Do nothing

Noise control



Equaliser



Voice assistant



Volume



Do nothing





# TOUCH CONTROLS

Touch the left or right earbud to control music, manage calls, and more. Touch controls can be customized in the Marshall Bluetooth app.

- Play / Pause
- ● Skip forward or Answer/ End call
- ● ● Skip backward

● Long touch to toggle noise cancelling, transparency and ANC off

*\*CUSTOM ACTION needs to be set first (left or right).*

## Active Noise Cancelling (ANC)

Blocks out your surroundings and lets you focus on the music.

## Transparency

Allows you to hear your surroundings and hold conversations without removing your earbuds.

## Off

Noise control is turned off.

● ● Double tap and hold to play a recommendation based on your listening taste

*\*To use Spotify Tap, make sure your Spotify app is up to date.*



## TOUCH CONTROLS (3 MODE)

Standard

Mini

Off

# TOUCH CONTROLS > Standard



## TOUCH CONTROLS



Standard

Mini

Off

### MEDIA

### CALL

Play/Pause



Skip forward



Answer/End call

Skip backward



Spotify Tap



Custom actions



Reject call

### CUSTOM ACTIONS

Left earbud

Noise control >

Right earbud

Equaliser >

# TOUCH CONTROLS > Mini



## TOUCH CONTROLS



Standard

Mini

Off

### MEDIA

### CALL

-



-

Play/Pause



Answer/End call

-



-

Spotify Tap



-

Custom actions



Reject call

### CUSTOM ACTIONS

Left earbud

Noise control >

Right earbud

Equaliser >

# TOUCH CONTROLS > Off



## TOUCH CONTROLS



Standard

Mini

Off

**MEDIA**

**CALL**

- |   |     |   |
|---|-----|---|
| - | •   | - |
| - | ••  | - |
| - | ••• | - |
| - | • — | - |
| - | —   | - |

**CUSTOM ACTIONS**

Left earbud - >

Right earbud - >



## **TOUCH CONTROLS**

Customise your earbud touch controls.



## **SPOTY TAP**

Get to know Spotify Tap.



## **INTERACTION SOUNDS**

Customise the Motif II A.N.C. audio prompts.



## **AUTO-PLAY/PAUSE**

In-ear detection will auto-pause and resume playback.



## **BATTERY PRESERVATION**

Extend the battery life span of your earbuds.



## **ABOUT**

Product identifiers and Firmware status.



## **FORGET DEVICE**

Remove Motif II A.N.C. from this app.



# TOUCH CONTROLS

Customise your earbud touch controls.



Standard	MEDIA	CALL
	Play/Pause	-
	Skip forward	Answer/End call
	Skip backward	-
	Spotify Tap	-
	Custom actions	Reject call

Mini	MEDIA	CALL
	-	-
	Play/Pause	Answer/End call
	-	-
	Spotify Tap	-
	Custom actions	Reject call

Off	MEDIA	CALL
	-	-
	-	-
	-	-
	-	-
	-	-



## SPOTIFY TAP

Get to know Spotify Tap.



Spotify - Music and Podcasts

Listen to Songs and Playlists

Update

★★★★★ 1.1M

Spotify


No. 1 Music

# GET STRAIGHT TO THE MUSIC WITH SPOTIFY TAP

Spotify Tap is music to your ears, quite literally. Get the tunes playing with a simple gesture on either left or right earbud.


### START THE MUSIC

Double tap and hold to start playing music based on your listening taste.



### CHANGE THE MUSIC



Double tap and hold again to skip the tune and cue up new recommendations just for you.





## INTERACTION SOUNDS

Customise the Motif II A.N.C. audio prompts.







## AUTO-PLAY/PAUSE



In-ear detection will auto-pause and resume playback.





# BATTERY PRESERVATION

Extend the battery life span of your earbuds.



**STANDARD**

**PRESERVATION** **STANDARD**

Temperature limit

Only charge in room temperature

Max. charge limit

Restrict battery charge to 90%

Charging speed **Fast**

Earbuds charging speed, fast or default

**MEDIUM**

**PRESERVATION** **MEDIUM**

Temperature limit

Only charge in room temperature

Max. charge limit

Restrict battery charge to 90%

Charging speed **Default**

Earbuds charging speed, fast or default

**MAX.**

**PRESERVATION** **MAX.**

Temperature limit

Only charge in room temperature

Max. charge limit

Restrict battery charge to 90%

Charging speed **Default**

Earbuds charging speed, fast or default



## ABOUT

Product identifiers and Firmware status.



Name MOTIF II A.N.C.

Model MOTIF II A.N.C.

Serial number 73400553E333B5B002734  
8

Firmware version 5.8.40

The firmware is up to date.

[View firmware version update here](#)



## FORGET DEVICE

Remove Motif II A.N.C. from this app.



### ARE YOU SURE?

Your Marshall device will be removed from the app. Just add the device again to bring it back.

**FORGET DEVICE**

Cancel

ash